

Price Computing Scale – AP

User Manual




**SNOWREX INTERNATIONAL
CO., LTD.**
SRAP200808

Table of Contents

Table of Contents.....	1
Specification.....	2
Basic specification.....	2
Series specification.....	2
Operation	3
Keys.....	3
Normal unit price input	3
PLU Data setting	3
Loading PLU	4
Modify PLU	5
Operation of M+	6
Operation of MR	6
PLU & ACC Mode Description	7
Setting and Calibration	8
General setting.....	8
Calibration Procedure.....	9
RS 232 Setting.....	10


5. Zero Point Calibration

XXXXX 0 Pnt 0	The first line shows AD Value, the second line shows "0", and the third line shows "Pnt 0."
---------------------	---

Remove weight from pan. Wait for the AD value is stable, press  key to enter next step.


6. Calibration by 1/3 of the maximum capacity

XXXXX 2000 Pnt 1	The first line shows AD Value, the second line shows the weight of 1/3 of the maximum (Unit: gram), and the third line shows "Pnt 1."
------------------------	---

Put on poise of the 1/3 weight by the maximum capacity. Wait for the AD value is stable, press  key to enter next step.


7. Calibration by 2/3 of the maximum capacity

XXXXX 4000 Pnt 2	The first line shows AD Value, the second line shows the weight of 2/3 of the maximum (Unit: gram), and the third line shows "Pnt 2."
------------------------	---

Put on poise of the 2/3 weight by the maximum capacity. Wait for the AD value is stable, press  key to enter next step.

8. Calibration by the maximum capacity

XXXXX 6000 Pnt 3	The first line shows AD Value, the second line shows the maximum weight (Unit: gram), and the third line shows "Pnt 3."
------------------------	---

Put on poise of full capacity of the scale. Wait for the AD value is stable, press  key to enter next step.

9. Take off poise from pan, and the instrument will restart automatically.



RS 232 Setting

The AP Series scale supports RS 232 configuration is 9600-8-N-1. It will output weight data when the weight is stable.

Calibration Procedure

Notice: This section can only be operated by engineers.

Please remove the jumper JP3 before you start the calibration process. Put the JP3 jumper back after the calibration is complete.

During the Calibration procedure, press  to switch selection, and press  to accept setting.

1. SEL maximum capacity

SEL value	Maximum Capacity
06	6 kg
15	15 kg
30	30 kg

2. Decimal point

	Explanation
dP 0	No decimal point
dP 0.0	One digit behind decimal point
dP 0.00	Two digits behind decimal point

3. Debug setting

	Explanation
dEBUG 0	Use as in the normal mode.
dEBUG 1	When in weighing mode, the third line of LCD is zero point or the zero point after taring, the division is 0.1g; the second line shows current weight and the division is 0.1g.

4. Zero tracking

	Explanation
trACH 0	Zero tracking disable
trACH 1	Zero tracking enable

Specification

Basic specification

Display Digit	LCD, height 14.5mm, 6/7/7(Weigh/Unit Price/ Total)
Platter Size(mm)	245 x 355(WxH)
Dimensions(mm)	387x365x117(WxLxH)
Net Weight(kg)	4.5kg(with pillar); 3.7kg(without pillar)
Operating Temperature	0° C to +40° C
Relative Humidity	Less than 85%
Power	9V / 500mA, AC adapter; Built in 6V Rechargeable Battery
Interface	RS-232C 9600-8-N-1

Series specification

Model	AP-6D	AP-15D	AP-30D
Max₁ / Max₂=	3kg / 6kg	6kg / 15kg	15kg / 30kg
Min₁ / Min₂=	20g / 3kg	40g / 6kg	100g / 15kg
e₁ / e₂=	1g / 2g	2g / 5g	5g / 10g
Accuracy	1/3000(Dual)	1/3000(Dual)	1/3000(Dual)

Operation

Keys

17 1	18 2	19 3	20 4	100g kg	7	8	9	Off
21 5	22 6	23 7	24 8	M+	4	5	6	On
25 9	26 10	27 11	28 12	MR	1	2	3	->0<-
29 13	30 14	31 15	32 16	PLU	0	00	C	T


Normal unit price input

- In weighing mode, pressing the white number keys to input the unit price. Total price will be automatically calculated when there is weight on the scale.
- When there is no weight on the scale, the unit price will be cleared in 3 seconds. However, the price will not be cleared when programming price into PLU.


PLU Data setting

Steps in setting PLU no. 1~32

1. Press white number key to enter Unit Price.


2. Press  key, and you should see the "PLU" flash on LCD.

3. Select the PLU key to set the PLU number

4. Press  key to save the setting. The "PLU" will stop flashing on LCD.

Setting and Calibration

1. Press and hold any key while turning the scale ON. It will show CAL on the LCD display.

2. Press  key to choose between CAL 1 and CAL 2.



3. Select CAL 1, press  key to enter general setting.

4. Select CAL 2, press  key to enter scale type setting.

Note:

- To perform calibration, you must remove the JP3 jumper from the MCU first. Put the JP3 back after calibration is complete.

General setting

During the procedure, Press  key for switching your selection, and  key is used for confirm/complete.








1. AoFF – Sleep mode setting

AoFF value	Explanation
0	Shut off sleeping mode.
1	If no operation, enter sleeping mode in 5 minutes.
2	If no operation, enter sleeping mode in 10 minutes.
3	If no operation, enter sleeping mode in 20 minutes.
4	If no operation, enter sleeping mode in 30 minutes.

2. BL Backlight setting

BL value	Explanation
0	Shut down backlight
1	Turn on backlight
2	Automatic backlight







PLU & ACC Mode Description

Appearance	Mode Description
Neither PLU LCD nor ACC LCD light up or flash	Weighing Mode ➤ Able to input the unit price
PLU light up, not flash.	PLU unit price indication ➤ PLU setting is finished.
PLU flashing	PLU setting mode 1 ➤ During PLU setting, please input the PLU set to be saved and press  to finish.
1. PLU light up, no flash. 2. The number below PLU keep flashing.	Loading PLU mode ➤ During PLU reading, please input the PLU number, and press  to complete.
ACC light up, no flash. Numbers in weight column.	ACC accumulation indication ➤ Several sets of data have been saved. Press  to enter circulating data display mode.
ACC flashing	Show ACC memory mode. ➤ The number above ACC is the set of the data. No weighing function at this moment. ➤ Press  to circulate and display data. ➤ Press  to go back to weighing mode.
1. ACC light up, no flash. 2. The weight column is empty. 3. The unit price column shows TOTAL	Total price display mode ➤ The number above ACC is the set of data. No weighing function at this moment. ➤ Total price column is the price summation of all the data. ➤ Press  key to clear all data. ➤ Press  to return to weighing mode.



Example

1. Press

5	0	0
---	---	---

 which means the unit price is 500.
2. Press  key, now "PLU" flash on LCD.
3. Press  key, PLU digits shows 13, and  now flashing.
4. Press  key again, PLU digits shows 29 instead, and  flashing.
5. Press  key, after the beep sound, the price setting for PLU 29 is done and set as 500.

Steps in setting PLU no.0~999




1. Press white number key to set unit price.
 2. Press  and you will see "PLU" flash on LCD.
 3. Press white number key to select PLU number.
 4. Press  to complete setting, "PLU" stop flashing on LCD.
- If the input isn't completed within 30 seconds, the setting will be suspended and exit to normal weighing mode.

Loading PLU




Steps in loading PLU no.1-32

- In weighing mode, pressing any key from the left 16 number keys will access the PLU memory of the key's lower-right set at once.
- If you press the same key again, it will access the PLU memory of the key's upper-left set



Example

1. Press  one time, the 13th PLU is loaded. The LCD shows 13.
2. Press  again, the 29th set's PLU memory, LCD shows 29.
3. Press  to access 1st set's PLU memory, LCD shows 1.




Steps in loading PLU no.0-999

1. In weighing mode, press and hold  key until double beep sound arise then release  key.
2. Press the white number keys to input the desired PLU number.
3. Press  key again, and the reference PLU is loaded.





Modify PLU

1. First load the PLU you want to modify. Press  key and you will see the Unit Price flashing.
2. Press white number keys to set unit price.
3. Press  to save the setting. The Unit Price stops flashing, and the price is updated.


Example

1. Press  one time, the 13th PLU is loaded. The LCD shows 13 and its unit price.
2. Press  key and the Unit Price starts flashing.
3. Input the new price using the white number keys.
4. Press  to save the setting.










Operation of M+

1. When there is a load on the weighing pan and unit price has been input, Press  key and after a beep sound,  will light up on the LCD, which means one data has been recorded.
2. Clear the load on the weighing pan and put another load on the weighing pan. Input the unit price and then press  key. After a beep sound,  will light up on the LCD, which means second data has been recorded.

Note:

- After each recording, if the load on the weighing pan is not cleared, pressing  will result in a long beep and the scale won't be able to record the next one.
- The stored memory can memorize up to 199 records.

Operation of MR

1. In weighing mode, press  key and the weight column will be cleared. The unit price column shows **total**. The total price column shows the total number of all memories. The number of data stored is shown above the "ACC" icon.
2. Press  key, the  will flash, weight column / unit price column / total price column shows the info of first data.
3. And then press  , the  will flash, weight column / unit price column / total price column shows the info of second data, Press  again to cycle through all the stored data.
4. If  is pressed, the current stored data will be removed from the memories.
5. When the scale shows total, pressing  will clear all the data.
6. Pressing  key to exit the MR mode without clearing the recorded data.